



Sun Path Products Inc. 404 W Edinborough Ave. Raeford, NC 28376 (910) 875-9002

## **PRODUCT ADVISORY NOTIFICATION**

**ISSUE DATE:** 11 March 2015

**SUBJECT:** MJ Reserve Housing / AAD Control Unit Contact

**STATUS:** Optional

### **IDENTIFICATION:**

A concern was reported that the Spectra Lanyard holding the reserve housing in place was long enough to potentially allow the end of the housing to rest on top of the AAD control unit and possibly turn the unit off or damage it.

### **Note:**

To date, Sun Path Products has not received any reports indicating damage to the AAD control unit or the pocket it resides in. The possibility of the AAD unit being turned off with indiscriminate housing movement is very remote.

The photo on the right shows the worst case scenario with the housing being forced into this position.



### **PRODUCT IMPROVEMENT NOTIFICATION:**

If this concern exists, an appropriately rated rigger may hand tack the housing down to hold it in place in the following manner.

Tools and Materials required:

- Hand Tack Needle.
- Waxed Super Tack Cord or Equivalent.



**Step 1.**

With the reserve canopy removed from the container, extract the AAD control unit from its pocket. Begin the hand tack from the back side of the reserve pin flap, as shown in the photo to the right.



**Step 2.**

Tack the white Spectra lanyard that secures the Oetiker clamp holding the housing in place with two (2) passes of doubled super tack. The red arrow shows the tack location.



**Step 3.**

Complete the hand tack with a Surgeon's knot followed by two (2) additional overhand knots on the back side of the flap.



**Step 4.**

Inspect work and reinstall AAD control unit into its pocket.

Work complete.



**AUTHORITY:**

Complete Parachute Solutions, Inc.

T.K. DONLE – Technical Director

[tk@cpsworld.com](mailto:tk@cpsworld.com)

Sun Path Products, Inc.

JEFF JOHNSTON – Engineering /R&D Manager

[jeff@sunpath.com](mailto:jeff@sunpath.com)

~~~ End of Notification ~~~